骨传导运动耳机 **OPENEAR Rondo**



配件清单

佩戴方式







说明书

耳棉 X2

产品信息


BT版本: 5.2

产品型号: OPENEAR Rondo 耳机类型: 骨传导运动耳机

连接范围:≈10米 麦克风灵敏度: -42db 续航时间:≥9小时(80%音量) 充电时间:≈1.5小时

按键示意图

充电电压: DC 5V



操作步骤

开/关机

开机:长按+键3秒,LED红蓝灯闪烁,提示音:power

使用说明书

关机:长按+键5秒,LED红灯闪烁,提示音:power

BT连接

打开蓝牙菜单,选择"OPENEAR Rondo"进行连接,提示音:connected.

接听/挂断/拒接来电

接听/挂断来电:单击+键。 拒接来电: 双击+键。

播放/暂停音乐

单击+键。

上/下一曲

上一曲: 三击+键。下一曲: 三击-键。

音量加/减

音量加:双击+键。音量减:双击-键。

唤醒语音助手

长按一键。

低电量提示

当电池低于5%时,每隔60秒红灯闪烁1下,低电量提示60秒循环一次,提示音"battery low"。

恢复出厂设置

关机状态下,长按+键10秒。

充电

请使用DC 5V的适配器进行充电,充电中红灯常亮,充 满电蓝灯常亮。



注意事项

- 1.长时间听大音量音乐可能会带来不适感,请尽可能
- 使用中等左右的音量,避免长时间使用大音量;
- 2.无论音量大小,使用耳机都将影响您对周围环境的 感知,使用耳机时多加注意;
- 3.切勿拆除或改装耳机,否则可能导致耳机故障或烧
- 4.切勿抛扔、坐压耳机或将其投入火中;
- 5.耳机应远离火、高电压设备;
- 6.不合适十岁以下儿童使用,内包含细小零件;
- 7.请勿将其归类为生活垃圾,而将其送往当地相应的 电器设备同收站。

注意: 若用户因违反以上警告内容造成的人身财产损 失,本公司不承担任何责任。

Bone Conduction Sports Headphones

OPENEAR Rondo

User Manual

How to Wear



What's In the Box



OPENEAR Rondo



Charging cable X1



Manual



Specifications

Model: OPENEAR Rondo

Type: Bone Conduction Headphones


BT Version: 5.2 Connection: ≈10m

Play Time: ≥9h(80%volume) Charging Time: ≈1.5h

Microphone: -42dB

Charging Voltage: DC 5V

Button Control



Operations

Power On/Off

Power On: Press & hold the button + for 3 sec, red & blue led flash. Prompt: power on pairing.

Power Off: Press & hold the button + for 5 sec, red led flash. Prompt: power off

BT Connection

Select "OPENEAR Rondo" in BT menu to connect. Prompt: connected.

Answer/Hang Up/Reject A Call

Answer/Hang Up A Call:Click the button + once. Reject A Call: Double click the button +.

Play/Pause Music

Click the button + once.

Previous/Next Track

Previous Track: Tripple click the button +. Next Track: Tripple click the button -

Volume Up/Down

Volume Up: Double click the button \pm . Volume Down: Double click the button -

Activate Voice Command

Press and hold the button -.

Low Battery


When battery is lower than 10%, prompt: battery low.

Restore Factory Setting

Under power-off mode, press and hold the button + for 10sec.

Charge

Please use DC 5V adapter for charging.Red LED is on charging. Blue LED is on after fully charged.



Attentions

- 1. Listening to loud music for a long time may cause discomfort, please use medium volume if possible. Do not use high volume for long periods of time.
- 2. Using headphones will affect your perception of the surrounding environment. Pay more attention when using headphones.
- 3. Do not remove or modify the headphone, as this may cause damage or burn out.
- 4. Do not throw, twist on headphones or put them into
- 5. Keep it away from fire, hydration and high pressure
- 6. Not suitable for children under 10-year-old containing small parts.
- 7. Do not classify it as household waste. Please send it to the local electrical equipment recycling station.

Note: The company does not assume any responsibility for the loss of personal property caused by the violation of the above warnings.