































<h1>Rhyme Band</h1> <h2>助跑器</h2> <h3>User Manual</h3> <h3>使用说明书</h3>	<h4>佩戴方式</h4>  <p>① 连接头带与两边主机</p>  <p>② 按住多功能键3秒开机</p>  <p>③ 戴上“Rhyme Band”</p>  <p>④ 享受你的运动</p> <h4>配件清单</h4>  <p>Rhyme Band X1</p>  <p>说明书 X1</p>  <p>充电盒和数据线</p>	<h4>产品信息</h4> <p>耳机型号: Rhyme Band 耳机类型: 助跑器 蓝牙版本: BT 5.1 连接距离: ≥10米 音乐时间: ≥6小时 (80%音量) 通话时间: ≥5小时 (80%音量) 充电时间: ≈2小时 充电电压: DC 5V</p> <h4>按键示意图</h4> 	<h4>开机配对</h4> <p>同时按住左右主机多功能键3秒, LED白绿灯交替闪烁, 开机进入配对模式。提示音: power on pairing.</p>  <h4>蓝牙连接</h4> <p>在蓝牙菜单内选择“Rhyme Band”进行配对, 连接成功提示音: connected.</p> 	<h4>关机</h4> <p>同时按住左右主机多功能键3秒, LED绿灯闪烁三次关机。提示音: power off.</p>  <h4>接听/挂断电话</h4> <p>单击左右主机任意一边多功能键。</p> 
<h4>拒接电话</h4> <p>双击左右主机任意一边多功能键。</p>  <h4>上/下一曲</h4> <p>上一曲: 长按左右主机任意一边+键。 下一曲: 长按左右主机任意一边-键。</p> 	<h4>播放/暂停音乐</h4> <p>单击左右主机任意一边多功能键。</p>  <h4>音量加/减</h4> <p>音量加: 单击左右主机任意一边+键。 音量减: 单击左右主机任意一边-键。</p> 	<h4>唤醒语音助手</h4> <p>三击左右主机任意一边多功能键。</p>  <h4>低电量提示</h4> <p>当电池电量低于10%时, 耳机每隔30秒播报低电提示: battery low.</p> 	<h4>充电</h4> <p>左右主机根据L/R分别贴进充电座两侧, 充电时耳机绿灯常亮, 充满电白灯常亮。 请使用DC 5V适配器为设备充电。</p>  <h4>恢复出厂设置</h4> <p>关机状态下同时长按左/右多功能键10秒。</p> 	<h4>重要说明</h4> <ol style="list-style-type: none"> 长时间听大音量音乐可能会带来不适感, 请尽可能使用中等左右的音量, 避免长时间使用大音量; 无论音量大小, 使用耳机都将影响您对周围环境的感知, 使用耳机时多加注意; 切勿拆除或改装耳机, 否则可能导致耳机故障或烧毁; 切勿乱扔、坐压耳机或将其浸入水中; 耳机应远离火、水和高压设备; 不合适三岁以下儿童使用, 内包含细小零件; 请勿将其归类为生活垃圾, 而将其送往当地相应的电器设备回收站。 <p>注意: 若用户违反以上警告内容造成的人身财产损失, 本公司不承担任何责任。</p>

<h1>Rhyme Band</h1> <h2>Audio Headband Headset</h2> <h3>User Manual</h3>	<h4>How to Wear</h4>  <p>① Buckle the headband on the device.</p>  <p>② Press & hold the MFB button for 3 sec.</p>  <p>③ Wear Rhyme Band.</p>  <p>④ Enjoy your workouts!</p> <h4>What's In the Box</h4>  <p>Rhyme Band X1</p>  <p>Manual X1</p>  <p>Charging Station X1 USB Cable X1</p>	<h4>Specifications</h4> <p>Model: Rhyme Band Type: Wireless audio headset BT Version: BT 5.1 Connection: ≥10m Music Time: ≥6h (80% volume) Call Time: ≥5h (80% volume) Charging Time: ≈2h Charging Voltage: DC 5V</p> <h4>Button Control</h4> 	<h4>Power On</h4> <p>Press & hold the MFB on both left & right headsets for 3 sec until white & green LEDs flash. Enter pairing mode. Prompt: power on pairing.</p>  <h4>BT Connection</h4> <p>Select "Rhyme Band" in BT menu to connect. Prompt: connected.</p> 	<h4>Power Off</h4> <p>Press & hold the MFB on both left & right headsets for 3 sec until green LED flashes. Prompt: power off.</p>  <h4>Answer/Hang Up A Call</h4> <p>Click the MFB once on left or right headset.</p> 
<h4>Reject A Call</h4> <p>Double click the MFB on left or right headset.</p>  <h4>Previous/Next Track</h4> <p>Press & hold the button + on left or right headset for previous track. Press & hold the button - on left or right headset for next track.</p> 	<h4>Play/Pause Music</h4> <p>Click the MFB once on left or right headset.</p>  <h4>Volume Up/Down</h4> <p>Click the button + once on left or right headset for volume up. Click the button - once on left or right headset for volume down.</p> 	<h4>Voice Command</h4> <p>Quick triple click the MFB on left or right headset.</p>  <h4>Low Battery</h4> <p>When battery is lower than 10%, prompt: battery low.</p> 	<h4>Charging</h4> <p>Place the left and right headset onto the charging station. The green LED is on during charging. The white LED is on when fully charged. Please charge with DC 5V adapter.</p>  <h4>Restore Factory Setting</h4> <p>Under power-off mode, press & hold the MFB button on both left and right headsets for 10sec.</p> 	<h4>Attentions</h4> <ol style="list-style-type: none"> Listening to loud music for a long time may cause discomfort, please use medium volume if possible. Don't use high volume for long periods of time. Using headphones will affect your perception of the surrounding environment. Pay more attention when using headphones. Do not remove or modify the headphone, as this may cause damage or burn out. Do not throw, twist on headphones or put them into a fire. Keep it away from fire, hydration and high pressure equipment. Not suitable for children under 3-year-old containing small parts. Do not classify it as household waste. Please send it to the local electrical equipment recycling station. <p>Note: The company does not assume any responsibility for the loss of personal property caused by the violation of the above warnings.</p>